

Lab work: MAC addresses and switch MAC address table

- 1. Open the class computer (password = tllabra)
- 2. Open the network settings of your computer and make sure that only the TP-Link network card is used, other network cards can be turned off.
- 3. Assign IP addresses to computers (TP-Link network card) using 192.168.5.0 /24 networks. (Please note that each computer has an unique IP address)
- 4. Build the network shown in the adjacent picture by connecting computers to a switch ports f0/13 and f0/15. Use Switch S1, so from the other computer, also connect the console connection (PC CON) to the console port on the switch (S1-con).



- 5. Use Putty-software and open the console connection to your switch and give it a name S1.
 - In Putty, use serial connection and COM-3 port
- 6. Test the connection between the computers with ping. If the connections do not work, find out what is wrong (ask your instructor for help if necessary) and try again.
- 7. Find the MAC addresses of the computers and note them down (use ipconfig/all command in your PC)
- 8. Check out the MAC address table on the switch. (Switch#show mac-address-table or show mac address-table)
 - What addresses appear on screen after that command
 - What MAC addresses can be found on ports f0/13 and f0/15?
 - Does the table content match the network you're building?
- 9. Change your network to match the picture below.



- 10. Connect the computers to ports f0/13 and connect the switches to each other from ports f0/17. Test your connection by pinging between computers.
- 11. Check the contents of the mac address table on switch S1. How the contents of the table have changed
- 12. Is it possible that there can be more than one address on the same port?
- 13. Return the switch's S1 mac address table as a text file to Moodle.