Exercise 6

The goal of the exercise is to get familiar with the operation of the ARP protocol, the use of mac addresses, as well as the MAC address table of the switch. RETURN to Moodle your answers to the questions presented, as well as the PC's ARP and switch MAC address table.

1. Find out your computer's MAC address

```
C:\Users\rashm>ipconfig -all
Windows IP Configuration
  Host Name . . . . . . . . . . : DESKTOP-C1S83NB
  Primary Dns Suffix . . . . . . :
  Node Type . . . . . . . . . . : Hybrid
  IP Routing Enabled. . . . . . . : No
  WINS Proxy Enabled. . . . . . . : No
  DNS Suffix Search List. . . . . : elisakoti
Wireless LAN adapter Local Area Connection* 1:
  Media State . . . . . . . . . . . Media disconnected
  Connection-specific DNS Suffix . :
  Physical Address. . . . . . . : AC-67-5D-56-80-E8
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Local Area Connection* 2:
  Media State . . . . . . . . . . . Media disconnected
  Connection-specific DNS Suffix . :
  DHCP Enabled. . . . . . . . . . : res
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Wi-Fi:
  Connection-specific DNS Suffix . : elisakoti
  Autoconfiguration Enabled . . . . : Yes
  Link-local IPv6 Address . . . . . : fe80::e35e:d4fb:d8db:5c42%3(Preferred)
  IPv4 Address. . . . . . . . . . : 192.168.100.10(Preferred)
  Subnet Mask . . . . . . . . . . : 255.255.255.0
  Lease Obtained. . . . . . . . : Monday, February 3, 2025 2:36:32 PM
  Lease Expires . . . . . . . . : Wednesday, February 5, 2025 6:29:06 AM
  Default Gateway . . . . . . . : 192.168.100.1
  DHCP Server . . . . . . . . . . : 192.168.100.1
  DHCPv6 IAID . . . . . . . . . . : 61630301
  DHCPv6 Client DUID. . . . . . . : 00-01-00-01-2E-73-BA-DE-AC-67-5D-56-80-E7
  DNS Servers . . . . . . . . . . : 192.168.100.1
                               192.168.100.1
  NetBIOS over Tcpip. . . . . . : Enabled
C:\Users\rashm>
```

- MAC address related to WI-FI: AC-67-5D-56-80-E7
- 2. Check out your computer's ARP table (arp-a)


C:\Users\rashm>arp -a Interface: 192.168.100.10 --- 0x3 Internet Address Physical Address Type 192.168.100.1 fc-3f-7c-94-53-cf dynamic 192.168.100.255 ff-ff-ff-ff-ff static 224.0.0.2 01-00-5e-00-00-02 static 224.0.0.22 01-00-5e-00-00-16 static 224.0.0.251 01-00-5e-00-00-fb static 224.0.0.252 01-00-5e-00-00-fc static 239.255.255.250 01-00-5e-7f-ff-fa static ff-ff-ff-ff-ff 255.255.255.255 static


- 3. Find out what the gateway address of your computer is
- Default Gateway : 192.168.100.1

```
C:\Users\rashm>ipconfig -all
Windows IP Configuration
  Host Name . . . . . . . . . : DESKTOP-C1S83NB Primary Dns Suffix . . . . . . :
  Node Type . . . . . . . . . . . . . . . . Hybrid
  IP Routing Enabled. . . . . . . : No
  WINS Proxy Enabled. . . . . . . . No
  DNS Suffix Search List. . . . . : elisakoti
Wireless LAN adapter Local Area Connection* 1:
  Media State . . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix . :
  Description . . . . . . . . . . . . Microsoft Wi-Fi Direct Virtual Adapter
  Physical Address. . . . . . . . . . . . AC-67-5D-56-80-E8
  DHCP Enabled. . . . . . . . . . . Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Local Area Connection* 2:
  Media State . . . . . . . . . . . . Media disconnected
  Connection-specific DNS Suffix . :
  Description . . . . . . . . . . . . Microsoft Wi-Fi Direct Virtual Adapter #2
  DHCP Enabled. . . . . . . . . . . Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Wi-Fi:
  Connection-specific DNS Suffix . : elisakoti
  Description . . . . . . . . : Intel(R) Wireless-AC 9461
  Physical Address. . . . . . . . . . AC-67-5D-56-80-E7
  DHCP Enabled. . . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
  Link-local IPv6 Address . . . . . : fe80::e35e:d4fb:d8db:5c42%3(Preferred)
  IPv4 Address. . . . . . . . . . : 192.168.100.10(Preferred)
  Lease Obtained. . . . . . . . : Monday, February 3, 2025 2:36:32 PM
  DICE C----- 192.160.100.1
  DHCPv6 IAID . . . . . . . . . . : 61630301
  DHCPv6 Client DUID. . . . . . . : 00-01-00-01-2E-73-BA-DE-AC-67-5D-56-80-E7
  DNS Servers . . . . . . . . . : 192.168.100.1
                                  192.168.100.1
  NetBIOS over Tcpip. . . . . . : Enabled
```

- 4. Open the Packet Tracer program and build the network shown in the illustration.
- Connect computers to ports F0/1 and connect switches to each other from ports F0/24.


• You can use the 2960 series switches.






5. Name the switches S1 and S2


```
Switch>enable
Switch#config t
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#hostname S1
S1(config)#
```




6. Assign IP addresses to computers. Use the 192.168.6.0 /24 network



7. Check out the ARP table on both computers. What addresses appear on the table?






8. Ping to test the connection between computers and check the ARP table again. Has anything changed?

Then the ARP table shows the data.

```
Config Desktop Programming
Physical
                                      Attributes
Command Prompt
C:\>arp -a
No ARP Entries Found
C:\>ping 192.168.6.2
Pinging 192.168.6.2 with 32 bytes of data:
Reply from 192.168.6.2: bytes=32 time<1ms TTL=128
Reply from 192.168.6.2: bytes=32 time<1ms TTL=128
Reply from 192.168.6.2: bytes=32 time=8ms TTL=128
Reply from 192.168.6.2: bytes=32 time<1ms TTL=128
Ping statistics for 192.168.6.2:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 8ms, Average = 2ms
C:\>arp -a
  Internet Address
                        Physical Address
                                               Type
  192.168.6.2
                        0002.4a8a.96b0
                                               dynamic
C:\>ping 192.168.6.3
Pinging 192.168.6.3 with 32 bytes of data:
Reply from 192.168.6.3: bytes=32 time=5ms TTL=128
Reply from 192.168.6.3: bytes=32 time=3ms TTL=128
Reply from 192.168.6.3: bytes=32 time=5ms TTL=128
Reply from 192.168.6.3: bytes=32 time=8ms TTL=128
Ping statistics for 192.168.6.3:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 3ms, Maximum = 8ms, Average = 5ms
C:\>arp -a
  Internet Address
                        Physical Address
                                               Type
  192.168.6.2
                         0002.4a8a.96b0
                                               dynamic
C:\>
```



9. Find out what the switch arp table looks like (Switch#show arp)

```
Switch>enable
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#hostname S2
S2(config)#exit
S2#
%SYS-5-CONFIG_I: Configured from console by console
S2#show arp
S2#
```

The ARP table is empty in the Switch

What you should to do that it's possible to see arp-table on the switch?

•

- Set an IP address to the switch and enable it.
- Why arp table of the switch is empty?

•

o Because the Switch do not have a IP address

•

o The switch may be operating as a Layer 2 device without its own IP interface.

•

 No IP traffic (and thus no ARP requests/replies) has been generated by the switch.

```
Switch>enable
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#hostname S2
S2(config)#exit
S2#
%SYS-5-CONFIG_I: Configured from console by console
S2#show arp
S2#
```

10. Check the contents of the switch's mac address table

• If mac address table is empty, you should ping between computers again

```
Request timed out.
Reply from 192.168.6.253: bytes=32 time<1ms TTL=255
Reply from 192.168.6.253: bytes=32 time<1ms TTL=255
Reply from 192.168.6.253: bytes=32 time<1ms TTL=255
Ping statistics for 192.168.6.253:
    Packets: Sent = 4, Received = 3, Lost = 1 (25% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 0ms, Average = 0ms
C:\>ping 192.168.6.253
Pinging 192.168.6.253 with 32 bytes of data:
Reply from 192.168.6.253: bytes=32 time<1ms TTL=255
Reply from 192.168.6.253: bytes=32 time<1ms TTL=255
Reply from 192.168.6.253: bytes=32 time<1ms TTL=255
Reply from 192.168.6.253: bytes=32 time=11ms TTL=255
Ping statistics for 192.168.6.253:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 11ms, Average = 2ms
C:\>ping 192.168.6.3
Pinging 192.168.6.3 with 32 bytes of data:
Reply from 192.168.6.3: bytes=32 time=9ms TTL=128
Reply from 192.168.6.3: bytes=32 time<1ms TTL=128
Reply from 192.168.6.3: bytes=32 time<1ms TTL=128
Reply from 192.168.6.3: bytes=32 time<1ms TTL=128
Ping statistics for 192.168.6.3:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 9ms, Average = 2ms
S2#show mac-address-table
        Mac Address Table
    _____
Vlan
      Mac Address
                          Type
                                      Ports
        -----
       0002.4a8a.96b0 DYNAMIC
0090.0ca7.a2ed DYNAMIC
00d0.bc39.6019 DYNAMIC
                                     Gig0/1
Fa0/24
   1
                                      Gig0/1
```

11. What's the difference between arp and mac address tables?

- ARP Table: Works at the network layer (Layer 3) to map IP addresses to MAC addresses.
- MAC Address Table: Works at the data link layer (Layer 2) to map MAC addresses to switch
- ARP Table: Used by devices to determine where to send IP packets on a local network.
- MAC Address Table: Used by switches to efficiently forward Ethernet frames to the correct destination.

RETURN to the Moodle: Answers to the questions asked and PC's arp table and switch mac address table. All in same file

Repository Link

Link: https://github.com/Rashmika-Dineth/Information-Networks/tree/main/Task%206